


UniCredit Hungary Bank Zrt. – user guide for PSD2 compliant token version DP310



[Click on the content table to navigate!](#)





Buttons of the token	2
First steps	2
Login to UniCredit's Internet Banking applications	4
Sign payment orders in UniCredit's Internet Banking applications	6
PIN change	9
Blocking the token PIN	14
Unlocking the PIN	19
Change the language	22
Token settings	26

Buttons of the token









First steps

No.	Action	Display	Comment
1.	Press the green ON/OFF button to turn the token on.		Hold it for at least 1 second.
2.	Enter your confidential 4-digit-long PIN then press OK.		





	<p>Confirm the new PIN then press OK.</p>		
<p>3.</p>	<p>Press the green OK button then continue from step 2 with another PIN.</p>		<p>The chosen PIN is too weak, therefore it cannot be used. The codes 1234, 5555, 8765 and alike are not allowed.</p>
			<p>The new PIN has successfully changed.</p>
<p>4.</p>	<p>Press the green OK button then continue from step 2.</p>		<p>The repeated PIN differs from the initially entered PIN, so the process restarts.</p>





Login to UniCredit's Internet Banking applications


No.	Action	Kijelző	Comment
1.	Press the green ON/OFF button to turn the token on.		Hold it for at least 1 second.
2.	Enter your confidential 4-digit-long PIN then press OK.		
3.			You have entered the correct PIN.
	Press the green OK button twice then continue from step 2.		Incorrect PIN was entered, therefore the login was not successful.

<p>4.</p>	<p>Press the green OK button to generate a password.</p>		<p>The one time login password can be generated here.</p>
<p>5.</p>	<p>Enter the displayed code into the appropriate pass-word field in the application</p>		<p>The password can be enlarged by pressing the green OK button.</p>





Sign payment orders in UniCredit's Internet Banking applications





No.	Action	Display	Comment
1.	Press the green ON/OFF button to turn the token on.		Hold it for at least 1 second.
2.	Enter your confidential 4-digit-long PIN then press OK.		
3.			You have entered the correct PIN.
	Press the green OK button twice then continue from step 2.		Incorrect PIN was entered, therefore the login was not successful.





<p>4.</p>	<p>Press the purple right arrow button once.</p>		
<p>5.</p>	<p>Press the green OK button to start the creation of a new signature code.</p>		
<p>6.</p>	<p>Enter the 6-digit-long account ID displayed by the Internet Banking app.</p>		
<p>7.</p>	<p>Enter the total amount of the payment.</p>		<p>The digits are shifted from the right side of the display, so for integer numbers two zeros are also required.</p>





5.	Enter the displayed code into the appropriate pass-word field in the application	 A OneSpan keypad with a small LCD screen at the top displaying "Signature code: 123456". Below the screen is a numeric keypad with buttons for digits 1-9, 0, and a red 'X' button. To the right of the numeric keypad are three blue navigation buttons (right arrow, left arrow, and a central 'OK' button with 'ON/OFF' text below it). The OneSpan logo is at the bottom right of the keypad.	The password can be enlarged by pressing the green OK button.
----	--	---	---



PIN change

No.	Action	Display	Comment
1.	Press the green ON/OFF button to turn the token on.		Hold it for at least 1 second.
2.	Enter your confidential 4-digit-long PIN then press OK.		
3.			You have entered the correct PIN.
	Press the green OK button twice then continue from step 2.		Incorrect PIN was entered, therefore the login was not successful.

<p>4.</p>	<p>Press the purple right arrow button twice.</p>		
<p>5.</p>	<p>Press the green OK button.</p>		
<p>6.</p>	<p>Press the green OK button.</p>		
<p>7.</p>	<p>Enter your confidential 4-digit-long PIN then press OK.</p>		





8.			You have entered the correct PIN.
	Press the green OK button twice then continue from step 2.		Incorrect PIN was entered, therefore the login was not successful.
9.	Enter your confidential 4-digit-long PIN then press OK.		
10.	Confirm the new PIN then press OK.		





	<p>Press the green OK button then continue from step 2 with another PIN.</p>		<p>The chosen PIN is too weak, therefore it cannot be used. The codes 1234, 5555, 8765 and alike are not allowed.</p>
<p>11.</p>			<p>The new PIN has successfully changed.</p>
<p>11.</p>	<p>Press the green OK button then continue from step 2.</p>		<p>The repeated PIN differs from the initially entered PIN, so the process restarts.</p>
<p>12.</p>	<p>Press the red <i>Back</i> button.</p>		





13.	Press the red <i>Back</i> button.		
14.			





Blocking the token PIN



In case incorrect PINs are used then the token displays a warning message twice. After that a time penalty is enforced for 1 minute also twice, and finally the token will be blocked.

No.	Action	Display	Comment
1.	Press the green ON/OFF button to turn the token on.		Hold it for at least 1 second.
2.	Enter an incorrect 4-digit-long PIN then press OK.		
3.			Incorrect PIN was entered, therefore the login was not successful.
4.	Press the green OK button.		There has been 1 unsuccessful login attempt.





<p>5.</p>	<p>Enter an incorrect 4-digit-long PIN then press OK.</p>		
<p>6.</p>			<p>Incorrect PIN was entered, therefore the login was not successful.</p>
<p>7.</p>	<p>Press the green OK button.</p>		<p>There have been 2 unsuccessful login attempts.</p>
<p>8.</p>	<p>Enter an incorrect 4-digit-long PIN then press OK.</p>		





9.			<p>Incorrect PIN was entered, therefore the login was not successful.</p>
10.			
11.	<p>Press the green OK button.</p>		<p>There have been 3 unsuccessful login attempts.</p>
12.	<p>Enter an incorrect 4-digit-long PIN then press OK.</p>		





13.			Incorrect PIN was entered, therefore the login was not successful.
14.			
15.	Press the green OK button.		The last chance to enter a correct PIN.
16.	Enter an incorrect 4-digit-long PIN then press OK.		

17.		 <p>The image shows a OneSpan token screen with a green display area at the top displaying the text "Wrong PIN" and "<OK>". Below the display is a numeric keypad with buttons for digits 1 through 9, 0, and a red "X" button. There are also navigation buttons: a blue right arrow, a blue left arrow, and a green "OK" button with "ON/OFF" text below it. The OneSpan logo is visible at the bottom right of the device.</p>	<p>Incorrect PIN was entered, therefore the login was not successful.</p>
18.		 <p>The image shows a OneSpan token screen with a green display area at the top displaying the text "PIN locked!" and "<OK>". Below the display is a numeric keypad with buttons for digits 1 through 9, 0, and a red "X" button. There are also navigation buttons: a blue right arrow, a blue left arrow, and a green "OK" button with "ON/OFF" text below it. The OneSpan logo is visible at the bottom right of the device.</p>	<p>The token is blocked, please call your relationship manager or the call center at the following number: +36-1/325-3200.</p>





Unlocking the PIN





No.	Action	Display	Comment
1.	Press the green ON/OFF button to turn the token on.		Hold it for at least 1 second.
2.	Press the green OK button.		
3.	Tell your relationship manager the displayed 7-digit-long code then press the green OK button.		
4.	Enter the 8-digit-long unlock code that you received from the Bank then press the green OK button.		In case some digits of the unlock code were mistyped from then the wrong numbers can be corrected with the help of the red <i>Delete</i> button.





			<p>The unlock was successful.</p>
<p>5.</p>	<p>Please check the unlock code with your relationship manager then continue from step 4.</p>	 	<p>Wrong unlock code has been entered, so the device is still locked.</p>
<p>6.</p>	<p>Enter your confidential 4-</p>		



7.	<p>Confirm the new PIN then press OK.</p>		
	<p>Press the green OK button then continue from step 4 with another PIN.</p>		<p>The chosen PIN is too weak, therefore it cannot be used. The codes 1234, 5555, 8765 and alike are not allowed.</p>
8.			<p>The new PIN has successfully changed.</p>
	<p>Press the green OK button then continue from step 6.</p>		<p>The repeated PIN differs from the initially entered PIN, so the process restarts.</p>

Change the language





No.	Action	Display	Comment
1.	Press the green ON/OFF button to turn the token on.		Hold it for at least 1 second.
2.	Enter your confidential 4-digit-long PIN then press OK.		
3.			You have entered the correct PIN.
	Press the green OK button twice then continue from step 2.		Incorrect PIN was entered, therefore the login was not successful.





<p>4.</p>	<p>Press the purple right arrow button twice.</p>		
<p>5.</p>	<p>Press the green OK button.</p>		
<p>6.</p>	<p>Press the purple right arrow button.</p>		
<p>7.</p>	<p>Press the green OK button.</p>		




8.	Press the purple right arrow button.		
9.	Press the purple OK button.		The device will display the texts in Hungarian from now on.
10.			
11.	Press the red <i>Back</i> button.		

12.	Press the red <i>Back</i> button.		
13.			

Token settings

No.	Action	Display	Comment
1.	Press the green ON/OFF button to turn the token on.		Hold it for at least 1 second.
2.	Enter your confidential digit-long PIN then OK.		
3.			You have entered the correct PIN.
	Press the green OK button twice then continue from step 2.		Incorrect PIN was entered, therefore the login was not successful.

<p>4.</p>	<p>Press the purple left arrow button.</p>		
<p>5.</p>	<p>Press the green OK button</p>		
<p>6.</p>	<p>Press the green OK button to view the details.</p>		<p>The token displays the address of the website of the Bank, the phone number and the e-mail address.</p>
<p>7.</p>	<p>Press the green OK button to view the details.</p>		<p>The token displays the current battery level.</p>

<p>8.</p>	<p>Press the green OK button to view the details.</p>		<p>The token displays the serial number, which can also be seen on the back of the device.</p>
<p>9.</p>	<p>Press the green OK button to view the details.</p>		<p>The token displays the date and time by the internal clock of the device.</p>
<p>10.</p>	<p>Press the green OK button to view the details.</p>		<p>The token displays the firmware number.</p>